

AgriMetal INC.



LANDSCAPE BALE CHOPPER MODELS GA 110S-LS, GA 130S-LS & GA 200S-LS

OPERATOR'S MANUAL AND PARTS BOOK

**AGRIMETAL INC.
LANDSCAPE BALE CHOPPER**

WARRANTY

AgriMetal Incorporated (AgriMetal) warrants the new **Landscape Bale Chopper** to be free from defects in material, under normal use and service. Obligation under this warranty shall extend for a period of 1 year (12 months) following the date of delivery to the original purchaser and shall be limited to, at the option of AgriMetal, replacement or repair of any parts found, upon inspection by AgriMetal, to be defective.

WARRANTY CLAIMS

The purchaser claiming under this warranty shall submit a warranty claim in the prescribed form to AgriMetal or an Authorized Dealer, for inspection by an authorized company representative.

LIMITATIONS OF LIABILITY

This warranty is expressly in lieu of all other warranties expressed or implied and all other obligations or liabilities on our part of any kind or character, including liabilities for alleged representations or negligence. We neither assume nor authorize any other person to assume on our behalf, any liability in connection with the subsequent sale of the **Landscape Bale Chopper**.

This warranty shall not apply to any **Landscape Bale Chopper** which has been altered outside the factory in any way so as, in the judgement of AgriMetal, to affect its operation or reliability, or which has been subject to misuse, neglect or accident.

This warranty does not cover parts and accessories which are under separate guarantees from the manufacturers and where service can be obtained from their service facilities. No warranty is extended to regular service items such as lubricants, belts, paint and the like.

OPERATOR'S MANUAL

The Purchaser acknowledges having received training in the safe operation of the **Landscape Bale Chopper** and further acknowledges that AgriMetal does not assume any liability resulting from the operation of the **Landscape Bale Chopper** in any manner other than described in the Operator's Manual supplied at the time of purchase.

WARRANTY VOID IF NOT REGISTERED

AGRIMETAL LANDSCAPE BALE CHOPPER

WARRANTY REGISTRATION FORM & INSPECTION REPORT

WARRANTY REGISTRATION

This form must be filled out by the dealer and signed by both the dealer and the customer at the time of delivery.

Customer's Name _____ Dealer Name _____

Address _____ Address _____

City, State/Prov., Code _____ City, State/Prov., Code _____

Phone Number (____) _____

Bale Chopper Model _____

Serial Number _____

Delivery Date _____

DEALER INSPECTION REPORT

- ___ Rotor and Blower Turns Freely
- ___ Belt Tension Checked
- ___ Check Engine Fluid Levels
- ___ Pulleys Aligned
- ___ Fasteners Tight
- ___ Lubricate Machine

SAFETY

- ___ Check Engine Fluid Levels
- ___ Pulleys Aligned
- ___ All Decals Installed
- ___ Guards and Shields Installed and Secured
- ___ Review Operating and Safety Instructions

I have thoroughly instructed the buyer on the above described equipment which review included the Operator's Manual content, equipment care, adjustments, safe operation and applicable warranty policy.

Date _____

Dealer's Rep. Signature _____

Signature _____

The above equipment and Operator's Manual have been received by me and I have been thoroughly instructed as to care, adjustments, safe operation and applicable warranty policy.

Date _____

Owner's Signature _____

WHITE	YELLOW	PINK
AGRIMETAL INC.	DEALER	CUSTOMER

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE
1	Introduction	1
2	Safety	2
2.1	General Safety	3
2.2	Equipment Safety Guidelines	4
2.3	Safety Training.....	5
2.4	Safety Signs.....	5
2.5	Preparation	6
2.6	Battery Safety	6
2.7	Operating Safety	7
2.8	Transport Safety	8
2.9	Storage Safety	8
2.10	Refuelling Safety.....	8
2.11	Maintenance Safety	8
2.12	Gas Motor Safety	9
2.13	Sign-Off Form	10
3	Safety Sign Locations	11
4	Assembling	18
4.1	Machine Assembly.....	18
5	Operation	25
5.1	To the New Operator or Owner	25
5.2	Principle Components.....	26
5.3	Break-In	27
5.4	Pre-Operation Checklist.....	27
5.5	Controls	28
5.6	Operating	32
5.7	Storage	41
	5.7.1 Placing in Storage	41
	5.7.2 Removing from Storage	41
6	Service and Maintenance	42
6.1	Service	42
	6.1.1 Fuels, Fluids and Lubricants	42
	6.1.2 Servicing Intervals	43
	6.1.3 Service Record	51
6.2	Maintenance	52
	6.2.1 Changing Engine Oil	52

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE
6.2.2	Cleaning Engine and Machine	53
6.2.3	Drive Belts	54
6.2.3.1	Rotor and Gear Box Drive	54
6.2.3.2	Tub Rotation Gear Box Belt	55
6.2.3.3	Tub Rotation Drive	56
6.2.3.3.1	Belt Tightening	56
6.2.3.3.2	Belt Replacement	57
6.2.4	Blower Drive Belt	58
6.2.5	Unplugging	59
6.3	Repairs	60
6.3.1	Knife Replacement	60
7	Trouble Shooting	63
8	Specifications	64
8.1	Mechanical	64
8.2	Bolt Torque	65
9	Parts List	66
10	Index	86

SERIAL NUMBER LOCATION

Always give your dealer the serial number of your AgriMetal Landscape Bale Chopper when ordering parts or requesting service or other information.

The serial number plate is located where indicated. Please mark the number in the space provided for easy reference.



GA 200S-LS



GA 130S-LS

Model Number _____

Serial Number _____

**AGRIMETAL INC.
1006 PRINCIPALE
WICKHAM, QUEBEC
CANADA, J0C 1S0**

**TEL: (819) 398-6883
FAX: (819) 398-5311**