

AgriMetal

INC.



**SELF-PROPELLED
GREENS ROLLER
MODEL GR-660**

OPERATOR'S MANUAL

AGRIMETAL INC.
SELF-PROPELLED GREENS ROLLER

WARRANTY

AgriMetal Incorporated (AgriMetal) warrants the new Greens Roller to be free from defects in material, under normal use and service. Obligation under this warranty shall extend for a period of 1 year (12 months) following the date of delivery to the original purchaser and shall be limited to, at the option of AgriMetal, replacement or repair of any parts found, upon inspection by AgriMetal, to be defective.

WARRANTY CLAIMS

The purchaser claiming under this warranty shall submit a warranty claim in the prescribed form to AgriMetal or an Authorized Dealer, for inspection by an authorized company representative.

LIMITATIONS OF LIABILITY

This warranty is expressly in lieu of all other warranties expressed or implied and all other obligations or liabilities on our part of any kind or character, including liabilities for alleged representations or negligence. We neither assume nor authorize any other person to assume on our behalf, any liability in connection with the subsequent sale of the Greens Roller.

This warranty shall not apply to any Greens Roller which has been altered outside the factory in any way so as, in the judgement of AgriMetal, to affect its operation or reliability, or which has been subject to misuse, neglect or accident.

This warranty does not cover parts and accessories which are under separate guarantees from the manufacturers and where service can be obtained from their service facilities. No warranty is extended to regular service items such as lubricants, belts, tires, paint and the like.

OPERATOR'S MANUAL

The Purchaser acknowledges having received training in the safe operation of the Greens Roller and further acknowledges that AgriMetal does not assume any liability resulting from the operation of the Greens Roller in any manner other than described in the Operator's Manual supplied at the time of purchase.

WARRANTY VOID IF NOT REGISTERED

AGRIMETAL

SELF-PROPELLED GREENS ROLLER

WARRANTY REGISTRATION FORM & INSPECTION REPORT

WARRANTY REGISTRATION

This form must be filled out by the dealer and signed by both the dealer and the customer at the time of delivery.

Customer's Name _____ Dealer Name _____

Address _____ Address _____

City, State/Prov., Code _____ City, State/Prov., Code _____

Phone Number (____) _____

Greens Roller Model _____

Serial Number _____

Delivery Date _____

DEALER INSPECTION REPORT

- ____ Hydraulic Components in Good Condition
- ____ Steering Wheel Turns Freely
- ____ Chain Tension Checked
- ____ Chain and Sprockets Aligned
- ____ Fasteners Tight
- ____ Lubricate Machine
- ____ Check Tire Pressure
- ____ Retainer Installed in Drawer Pin
- ____ Check Fluid Levels

SAFETY

- ____ Safety Chain on Trailer Hitch
- ____ All Decals Installed
- ____ Guards and Shields Installed and Secured
- ____ Review Operating and Safety Instructions

I have thoroughly instructed the buyer on the above described equipment which review included the Operator's Manual content, equipment care, adjustments, safe operation and applicable warranty policy.

Date _____ Dealer's Rep. Signature _____

Signature _____

The above equipment and Operator's Manual have been received by me and I have been thoroughly instructed as to care, adjustments, safe operation and applicable warranty policy.

Date _____ Owner's Signature _____

WHITE	YELLOW	PINK
AGRIMETAL INC.	DEALER	CUSTOMER

SERIAL NUMBER LOCATION

Always give your dealer the serial number of your AgriMetal Self-Propelled Greens Roller when ordering parts or requesting service or other information.

The serial number plate is located where indicated. Please mark the number in the space provided for easy reference.



Model Number _____

Serial Number _____

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE
1	Introduction	1
2	Safety.....	2
2.1	General Safety.....	3
2.2	Equipment Safety Guidelines.....	4
2.3	Safety Training	5
2.4	Safety Signs.....	5
2.5	Preparation.....	6
2.6	Maintenance Safety	6
2.7	Operating Safety	7
2.8	Transport Safety	8
2.9	Storage Safety	8
2.10	Refuelling Safety	8
2.11	Tire Safety	8
2.12	Gas Motor Safety.....	9
2.13	Sign-Off Form.....	10
3	Safety Sign Locations	11
4	Assembling	13
4.1	Machine Assembly	13
5	Operation.....	17
5.1	To the New Operator or Owner	17
5.2	Machine Components.....	18
5.3	Break-In	19
5.4	Pre-Operation Checklist	19
5.5	Controls	20
5.6	Attaching/Unhooking.....	21
5.7	Loading Greens Roller onto Trailer	22
5.8	Field Operation.....	25
5.9	Transporting	32
5.10	Storage	33
6	Service and Maintenance	34
6.1	Service	34
6.1.1	Fluids and Lubricants	34
6.1.2	Greasing	34
6.1.3	Servicing Intervals.....	35
6.1.4	Service Record	40
6.2	Maintenance.....	41
6.2.1	Cleaning Air Cleaner	42
6.2.2	Changing Engine Oil.....	43
6.2.3	Changing Hydraulic Oil and Filter.....	44
6.2.4	Roller Chain Tension & Alignment	45
7	Trouble Shooting	45
8	Specifications	46
8.1	Mechanical	46
8.2	Hydraulic Fitting Torque	47
8.3	Bolt Torque	48
9	Index.....	49

AGRIMETAL INC.
1006 PRINCIPALE
WICKHAM, QUEBEC
CANADA, J0C 1S0

TEL: (819) 398-6883
FAX: (819) 398-5311